

INSTALLING NUTRI-MATE II PIVOT ARM

- 1- Install pivot arm in frame and secure with 3/4" bolt, nut & washer. Hand tighten only now.
- 2- Before tightening bolt, measure 2" from rear of pivot arm forward and mark this spot.
- 3- From this spot, swing pivot arm so that it is 2" away from frame. This is the position the pivot arm needs to be in when the bolt is tightened. A 2" block will greatly aid in holding pivot arm while tightening nut.
- 4- Tighten bolt to 250 in-lb to secure rubber bushing in frame.

